

Using the GoBackTrail USB Rechargeable Headlamp

Step 1

Fully charge the headlamp before use. The charge port is located inside the adjustment hinge area behind a rubber plug. First open the hinge area and then gently pull open the rubber charge plug. Plug one end of the USB charge cable into the headlamp. The other end you can plug into a phone charger, laptop or any other USB wall charger or 12v car phone charger. The button on top will glow red while it is charging and will change to green when it is fully charged.



Step 2

The head band is elastic and you can change the length to suit your head size. The band should be just tight enough that it won't fall down but not so tight as to cause discomfort.

Step 3


The hinge allows you to adjust the shine angle. This means you can tilt the light to the best angle so that the light is exactly where you need it most. The hinge will make a popping sound when you move it but that is what it is designed to do.



Headband Hinge

Step 4

If you wish you can attach your headlamp to a hat. Start by removing the head band by passing it through the slots.



Step 5

Once the headband is removed pull the hinged area down and you will see a chrome wire. This wire is the hat clamp. Spread it and place it on the brim of your hat.



Step 6

The head lamp has 3 modes, bright, normal and flashing red. Press the button on top once and it will be in bright mode. Quickly press it again and it will be in normal mode and once again, quickly press it again and it will be in flashing red mode.



Step 7

To turn off the headlamp after being turned on, just press the button again. If you press the button 4 times quickly it will turn on each mode and then turn the headlamp off.

Tips & Warnings

- ✦ The headlamp will survive light rain and mist but will not survive being submerged or heavy rain.
- ✦ You can recharge the battery with any rechargeable battery pack with USB ports.