

Tips on Using the GoBackTrail Fuel Canister Stove


Step 1

Choose a flat, stable surface to set your backpacking stove up on. Make sure the stove is not situated around anything flammable.



Step 2

Unfold the pot supports on the stove to the outward position. Make sure they are completely pushed down so they will be able to support a pot or cup.



Step 3

Remove the plastic cap from the top of the fuel canister. Place the cap in a protected area, so you can replace it when the canister is not being used. *(Note: You will use a Screw-On Fuel Canister. It contains a mix of butane and propane. This canister can also be called threaded, C100, C500, CA500 or 'normal'. It*

is reusable because it has a resealable “Lindal Valve”. This means you can remove the fuel canister from the stove and then reattach it later.)



This is an example fuel canister. There are many brands and they all seem to work just fine.

Step 4

Screw the fuel canister securely onto the bottom portion of the stove. Set the stove and fuel canister on the ground or any flat surface. The fuel canister will be the stove’s support.

Step 5

Turn the heat control valve slightly on. Light the stove by pushing the flame striker or by holding a match close to the burner.



Heat Control Valve

Flame Striker

Step 6

Place your pot on top of the pot supports. Adjust the flame by turning the heat control valve.

Step 7

Turn the heat control valve to the "off" position when you are finished cooking. Once the stove has cooled, remove the fuel canister and replace the plastic cap on top of it. Fold the pot supports inward and store the stove until you are ready to use it again.

Tips & Warnings

- ✦ Stove will be hot if it has just been used for cooking. Handle with care.
- ✦ Be sure to carry any empty fuel canisters out of the forest with you. Don't leave any trash behind.
- ✦ Discard any leftover food in an area away from your camp. Otherwise, you will attract wild animals to your campsite.